




TOP AND CONSOLE PARTS

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	693995	Screw, Hex	27	3403498	Connector, 3-Position (Gas Valve)
	LIT8535830	Instructions, Installation	10		Washer Head	28	3397695	Wire, Jumper (Guard On/Off)
	LIT8522243	Use & Care Guide		8557857	Screen, Lint	29	3390646	Screw, 8-18 x 5/16
	LIT3979703	Wiring Diagram		8557858	White	30	357213	Nut, Push-In (2)
	LIT8533770	Sheet, Cycle Feature	11	8536939	Biscuit	31	8299879	Harness, Wiring
Following May Be Purchased			12	8533971	Clip, Spring	32	3396029	Wire, Jumper (Temperature)
DO-IT-YOURSELF REPAIR MANUALS			13	688983	Screw, 8-18 x 5/8	33	3347243	Connector 6-Circuit
	LIT677818	Dryer	14	8533951	Screw, Grounding	34	3405156	Switch, Wrinkle Shield
2	3401684	Wire, Jumper (Black)	15	3395683	Connector (Motor)	39	3398095	Switch, Push-To-Start
3	694419	Buzzer, Mini	16		Top	48		Timer Knob Assembly
4		Cap, End (L.H.)		8557930	White		8544957	Grey
	8271365	White		8557931	Biscuit		8544958	Biscuit
	8271368	Biscuit	17	3400985	Medallion	52	94614	Terminal, Female
5	717252	Plug, 2-Way Terminal	18		Knob, Control (3)	53	8544895	Bracket, Control
6	8274261	Panel, Rear Console		8544937	Grey	54		Panel, Control (Includes Illus. 17)
7	3399639	Switch, Temperature	19	3394427	Clip-Harness		8545977	Grey
8		Cap, End (R.H.)	20	388326	Screw, Console		8545978	Gold
	8271359	White	21	8299766	Timer Assembly (60 Hz.)	55	3936144	Connector
	8271362	Biscuit	24	3397269	Connector-Timer			
			25	3401144	Connector, (PTS Relay)			
			26	3403499	Connector, 2-Position (Gas Valve)			


OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
ACCESSORY PARTS			PAINT, TOUCH-UP (1/2oz.)			PAINT, BULK (1 qt.)		
	279948	Kit, Dryer Repair		72017	White		799344	White (Uncut)
	346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)		4392899	Biscuit		4392900	Biscuit (Uncut)
	3406839	Dry Rack	PAINT, PRESSURIZED SPRAY (12 oz.)					
	8522199	Kit, Dryer Vent Testing		350930	White			
				4392901	Biscuit			
				350938	Primer, Gray			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10–32 x 5/8 (External Ground)	19	98234	Clip, Ground (2)	38	3406129	Seal & Bearing Assembly
2	343641	Screw, 10–16 x 1/2	20	690363	Lock, Front Top (2)	39		Plug, Front Panel
3	693995	Screw, Hex Head	21		Panel Front		3394975	White
4	8541400	Bracket, Cabinet		3395197	White		3394978	Biscuit
5	3396795	Cover, Block		3977243	Biscuit	45	344020	Cord, Power
6	3404162	Clamp, Motor (W/Shield)	23	685203	Clip, Felt Pad (2)	48	3394083	Clip, Front Panel
7	3396805	Panel, Rear	24	3389441	Catch, Door Assembly	51	238088	Hinge, Top (2)
8	8546676	Clip, Door Spring	25	3390731	Seal, Door	53	691366	Idler & Pulley Assembly
10	3406107	Door Switch Assembly	26	337189	Clip, Hinge (2)	56	8066065	Belt, Drive
11	697773	Screw, 6–20 x 7/8	27	694091	Screw, 8–18 x 3/8	57	348780	Base, Motor
13	3357011	Screw, 10–16 x 1/2	28	8066056	Hinge, R.H.	58	3400500	Bolt, 5/16–18 x 3/4
14	8541401	Spring, Door (2)		8066057	Hinge, L.H.	59	3394341	Pulley, 60 Hz.
16	3392100	Foot, Dryer	33	696144	Strike, Panel	62	8538262	Motor Assembly 60 Hz.
	279810	Foot–Optional (Extended Length) (Package of 2) (Not Included.)	35	695737	Door, Rear	63	660658	Clamp, Motor
17	342043	Screw, 10–32 x 3/8	36		Door, Front	67	8318272	Burner Assembly, 60 Hz.
18		Cabinet (Includes Illus. 4)		3393549	White			(See Pages 7 & 8 For Further Burner Breakdown)
	8530603	White		3977241	Biscuit	68	341029	Clamp, Pipe
	8530606	Biscuit	37		Handle, Door			
				690270	White			
				3977242	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8–18 x 5/8
3	3388703	Washer–Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8–18 x 3/8
6	487909	Screw, 8–15 x 1/2
7	3392519	Fuse, Thermal
8	8066086	Drum Hole Plug
9	3387134	Thermostat, Internal–Bias
10	694089	Wheel, Blower (Includes Illus. 21)
11	8557384	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10–16 x 1/2
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	280010	Kit, Thermal Cut–Off (Includes Illus. 15)
17	3390647	Screw, 8–18 x 1/2
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	3394196	Seal, Blower
22	3977373	Bracket, Drum Light
23	3406022	Bracket, Bulkhead
24	3401707	Wire, Jumper
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8–16
48	3403413	Bulkhead
49	338906	Sensor, Radiant
53	3402841	Lens, Drum Light
62	692526	Ring, Bearing
63	97787	Screw, 11–16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Models: LGR8648PW0, LGR8648PG0
(White/Grey) (Biscuit/Gold)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8–18 x 3/8
9		Orifice, Burner Type 1 234826 Type 4 (Butane) 229742 Type 4 (Propane) 234868
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8–32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1)
to Type (4) L.P.G.

BA–150

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST